

AT Command Set

For RF-BT0417C

1. Testing the connection

Before sending a AT command to the Bluetooth module, you will need to check the connection between the terminal software and the module.

Format: Send : AT // *Note: Capital letter*

Return: OK

2. Changing the default baud rate

Format: Send: AT+BAUD1 // *change baud rate to 1200*

Return: OK1200

1	1200	5	19200
2	2400	6	38400
3	4800	7	57600
4	9600	8	115200

3. Changing default name

Format: Send AT+NAMEyourname //yourname: *lowercase*

Return: OKyourname

4. Changing default password

Format: Send AT+PINxxxx //xxxx: *your new password*

Return: OKsetpin