

Telephone:  
Fax:  
VAT Registration No.:

---

## Meta M94A

### System operation

- Pressing remote control lock/unlock button once within 2 seconds of arming system deactivates interior movement sensors.

### Programming

**NOTE: Replacement remote controls already programmed.**

## Laserline 989

### System operation

- Pressing remote control lock/unlock button once within 30 seconds of arming system deactivates interior movement sensors.

### Synchronization

#### When

- Remote control battery completely discharged.
- Remote control battery replaced.

#### How

- Press and hold lock/unlock button **Fig. 1** [1].
- Wait until remote control LED switches OFF.
- Release held button.
- System should now lock or unlock vehicle.
- If not, carry out programming procedure.

### **Fig. 1**

### Programming

#### When

- Remote control added or replaced.
- System malfunction.

#### How

- Obtain all remote controls.
- Switch OFF alarm using remote control.
- Open driver's door.
- Switch ignition ON.
- Program remote control as follows:

- Press lock/unlock button 4 times within 10 seconds **Fig. 1** [1].

**NOTE: Alarm LED flashes each time lock/unlock button pressed.**

- Wait 10 seconds. Ensure alarm LED illuminates.
- Repeat above procedure to program remaining remote controls.

**NOTE: Start programming next remote control within 30 seconds.**

- Switch ignition OFF.

**NOTE: A maximum of 4 keys can be programmed.**

