





B-BOARD 
TNP8EB007


AV2
JK3001
TJB8E007

R OUT
R IN
L OUT
L IN
SLOW SW
5°C IN
VIDEO OUT
VIDEO IN




F, F1 GND = IF BLOCK GROUND
V GND = AV TERMINAL GROUND
M GND = SOUND RECORDING BLOCK GROUND
C GND = AV SWITCHING BLOCK AND GENERAL GROUND
D GND = DIGITAL BLOCK GROUND

E-BOARD TX-28MD3C



P-BOARD 
TNP8EP013



Y-BOARD TX-28MD3C/TX-25MD3C

