


## Remote control



- ① Standby/on switch [⏻]
- ② Sleep button [SLEEP]
- ③ FL display, Dimmer button [FL DISPLAY, -DIMMER]
- ④ Play mode, Mix 2ch button [PLAY MODE, -MIX 2CH]
- ⑤ Repeat button [REPEAT]
- ⑥ Cancel button [CANCEL]
- ⑦ Position memory button [POSITION MEMORY]
- ⑧ Skip, Preset channel, TV channel buttons [◀▶, SKIP, √ CH ▲]
- ⑨ Basic operation buttons
- ⑩ Top menu, Direct navigator button [TOP MENU, DIRECT NAVIGATOR]
- ⑪ Cursor buttons [▲, ▼, ◀, ▶], Enter button [ENTER]
- ⑫ Display, TV volume down button [DISPLAY, TV VOL-]
- ⑬ Volume buttons [-, +, VOLUME]
- ⑭ Muting button [MUTING]
- ⑮ Sound field, sound quality buttons
- ⑯ FM mode, Setup button [FM MODE, SETUP]
- ⑰ Zoom button [ZOOM]
- ⑱ AV system standby/on button [⏻, AV SYSTEM]
- ⑲ Source select buttons
  - Face towards this unit to change the source.
  - Press [TV] or [VCR/AUX] first to operate a Panasonic television or video cassette recorder.
- ⑳ TV/AV button [TV/AV]
- ㉑ Numbered buttons [1-9, 0, ≧10/-/-]
- ㉒ Slow/search, Tuning buttons [◀▶, SLOW/SEARCH]
- ㉓ Menu, Play list button [MENU, PLAY LIST]
- ㉔ Return, TV volume up button [RETURN, TV VOL+]
- ㉕ Audio button [AUDIO]
- ㉖ Group button [GROUP]

## Main unit

- ① Standby/on switch [⏻/⏻]
- Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.
- ㉗ Standby/on indicator
- When the unit is connected to the AC mains supply, this indicator lights up in standby mode and goes out when the unit is turned on.
- ㉘ Remote control signal sensor
- ㉙ RDS button [RDS]
- ㉚ SFC button [SFC]
- ㉛ Source select button [SELECTOR]  
DVD/CD→FM→AM→TV→VCR/AUX
- ㉜ Skip, Preset channel buttons [◀▶]
- ㉝ Subwoofer level button [SUBWOOFER]
- ㉞ Headphone jack [PHONES]
- ㉟ Disc tray
- ㊱ Display
- ㊲ Open/close button [▲, OPEN/CLOSE]
- ㊳ Basic operation buttons
- ㊴ Volume control [VOLUME, DOWN, UP]

## Subwoofer

- ㊵ AC supply indicator [AC IN]
- This indicator lights when the unit is connected to the AC mains supply.

