

E PANEL CIRCUIT

 : MAIN SIGNAL LINE



TO **C**
MAIN CIRCUIT
(CN601) ON
SCHEMATIC
DIAGRAM-18

J VOLUME
CIRCUIT

F SENSOR CIRCUIT

G TV/VCR INPUT CIRCUIT

TO **C**
MAIN CIRCUIT
(CN402) ON
SCHEMATIC
DIAGRAM-16