

# PIC16C5XX

## **EPROM/ROM Memory Programming/Verify Specification**

#### This document includes the programming specifications for the following devices:

- PIC16C52
  - PIC16C55 • PIC16C55A
- PIC16C54
- PIC16C54A • PIC16C56
- PIC16C54B
  - PIC16C56A • PIC16CR56A • PIC16C58A
- PIC16C54C
- PIC16CR54A

PIC16CR54C

- PIC16CR54B
- PIC16C58B PIC16CR58A

• PIC16C57

• PIC16C57C

PIC16CR57B

• PIC16CR57C

PIC16CR58B

### INTRODUCTION

#### Overview

The PIC16C5X Series is a family of single-chip CMOS microcontrollers with on-chip EPROM for program storage. The programming specification also applies to ROM products for verification only.

Due to the special architecture of these microcontrollers (12-bit wide instruction word) and the low pin counts (starting at 18 pins), the EPROM programming methodology is different from that of standard (bytewide) EPROMs (e.g., 27C256).

The PIC16C5X Series can be programmed by applying the 12-bit wide data word to the 12 available I/O pins while the address is generated by the on-chip Program Counter. The MCLR/VPP pin provides the programming supply voltage (VPP). Programming/verify chip enable is controlled by the T0CKI pin while the OSC1 pin controls the Program Counter.

This document describes all the programming details of the PIC16C5X Series and the requirements for programming equipment to be used from programming prototypes in the engineering lab up to high volume programming on the factory floor.

#### Pin Diagrams



#### PIN DESCRIPTIONS (DURING PROGRAMMING): PIC16C52/54/54A/54B/55/56/57/58A/58B

	During Programming					
Pin Name	Pin Name	Pin Type	Pin Description			
TOCKI	PROG/VER	I	Program pulse input/verify pulse input			
RA0 - RA3	D0 - D3	I/O	Data input/output			
RB0 - RB7	D4 - D11	I/O	Data input/output			
OSC1	INCPC	I	Increment Program Counter input			
MCLR/VPP	Vpp	Р	Programming Power			
Vdd	Vdd	Р	Power Supply			
Vss	Vss	Р	Ground			

Legend: I = Input, O = Output, P = Power

PIC16C5XX

## 1.0 PROGRAM/VERIFY MODES

The PIC16C5X Series uses the internal Program Counter (PC) to generate the EPROM address. VPP is supplied through the MCLR pin.

The TOCKI pin acts as chip enable, alternating between programming and verifying.

The OSC1 pin is used for incrementing the PC.

Data is applied to, or can be read on PORTA and PORTB (MSB on RB7, LSB on RA0).

The programming/verify mode is entered by raising the level on the MCLR pin from VIL to VHH (= VPP) while the T0CKI pin is held at VIH and the OSC1 pin is held at VIL.

The Program Counter now has the value "0xFFF", because  $\overline{\text{MCLR}}$  was at VIL before. This condition selects the configuration word as the very first EPROM location to be accessed after entering the program/verify mode.

Since the  $\overline{\text{MCLR}}$  pin was initially at VIL, the device is in the reset state (the I/O pins are in the reset state).

Incrementing the PC once (by pulsing the OSC1 pin) selects location "0x000" of the user program memory. Afterwards all other memory locations from 001h through end of memory can be addressed by incrementing the PC.

If the Program Counter has reached the last address of the user memory area (e.g. "0x1FF" for the PIC16C54), and is incremented again, the on-chip special EPROM area will be addressed. (See Figure 1-2 to determine where the special EPROM area is located for the various PIC16C5X devices).

#### 1.1 Program/Verify Without PC Increment

After entering the program/verify mode, pulsing the T0CKI pin LOW programs the data present on PORTA and PORTB into the memory location selected by the Program Counter. The duration of the T0CKI LOW time determines the length of the programming pulse.

Pulsing the <u>TOCKI</u> pin LOW again without changing the signals on MCLR and OSC1 puts the contents of the selected memory location out on PORTA and PORTB for verification of a successful programming cycle. This verification pulse on TOCKI can be much shorter than the programming pulse. If the programming was not successful, TOCKI can be pulsed LOW again to apply another programming pulse, followed again by a shorter TOCKI LOW pulse for another verification cycle.

This sequence can be repeated as many times as required until the programming is successful.

#### 1.2 Verify with PC Increment

If a verification cycle shows that programming was successful, the Program Counter can be incremented by keeping the T0CKI input at a HIGH level while pulsing the OSC1 input HIGH. When both T0CKI and OSC1 are HIGH, the contents of the selected memory location is put out on Ports A and B (= Verify). The falling edge of OSC1 will increment the Program Counter.

A fast VERIFY- ONLY with automatic increment of the PC can be performed by entering the program/verify mode as described above and then clocking the OSC1 input. If OSC1 is HIGH, the selected memory location is output on Ports A and B, while the falling edge of OSC1 will increment the Program Counter. Thus, the first memory location to be verified after entering the program/verify mode, is the configuration word. The next location is 000h followed by 001h and so on. The program memory location "N" can be reached by generating "N + 1" falling edges on OSC1. When OSC1 is brought HIGH again, the contents of address "N" are output on Ports A and B as long as OSC1 stays HIGH.

#### 1.3 <u>Programming/Verifying Configuration</u> Word

The configuration word is logically mapped at program memory location "0xFFF". The PC points to the configuration word after MCLR pin goes from LOW to VHH (HIGH). The configuration word can be programmed or verified using the techniques described in Section 1.1 and Section 1.2.

If PC is incremented, the next location it will point to is "0x000" in user memory. Incrementing PC 4096 times will not allow the user to point to the configuration word. The only way to point to it again is to reset and re-enter program mode.

#### 1.4 Programming Method

The programming technique is described in the following section. It is designed to guarantee good programming margins. It does, however, require a variable power supply for Vcc.

#### 1.4.1 PROGRAMMING METHOD DETAILS

Essentially, this technique includes the following steps:

- 1. Perform blank check at VDD = VDDmin. Report failure. The device may not be properly erased.
- Program location with pulses and verify after each pulse at VDD = VDDP: where VDDP = VDD range required during programming (4.75V - 5.25V).
- a) Programming condition:

VPP = 13.0V to 13.25V

VDD = VDDP = 4.75V - 5.25V

VPP must be  $\geq$  VDD + 7.25V to keep "programming mode" active.

b) Verify condition:

VDD = VDDP

 $VPP \ge VDD + 7.5V$  but not to exceed 13.25V

If location fails to program after "N" pulses, (suggested maximum program pulses of 8) then report error as a programming failure.

**Note:** Device must be verified at minimum and maximum specified operating voltages as specified in the data sheet.

- 3. Once location passes "Step 2", apply 11X overprogramming, i.e., apply eleven times the number of pulses that were required to program the location. This will guarantee a solid programming margin. The overprogramming should be made "software programmable" for easy updates.
- 4. Program all locations.
- Verify all locations (using speed verify mode) at VDD = VDDmin
- 6. Verify all locations at VDD = VDDmax

VDDmin is the minimum operating voltage spec. for the part. VDDmax is the maximum operating voltage spec. for the part.

#### 1.4.2 SYSTEM REQUIREMENTS

Clearly, to implement this technique, the most stringent requirements will be that of the power supplies:

**VPP**: VPP can be a fixed 13.0V to 13.25V supply. It must not exceed 14.0V to avoid damage to the pin and should be current limited to approximately 100mA.

**VDD**: 2.0V to 6.5V with 0.25V granularity. Since this method calls for verification at different VDD values, a programmable VDD power supply is needed.

#### Current Requirement:100mA maximum

Microchip may release PIC16C5Xs in the future with different VDD ranges which make it necessary to have a programmable VDD.

It is important to verify an EPROM at the voltages specified in this method to remain consistent with Microchip's test screening. For example, a PIC16C5X specified for 4.75V - 5.25V should be tested for proper programming from 4.75V - 5.25V.

Note:	Any programmer not meeting the program-
	mable VDD requirement and the verify at
	VDDmax and VDDmin requirement may
	only be classified as "prototype" or "devel-
	opment" programmer but not a production
	programmer.

#### 1.4.3 SOFTWARE REQUIREMENTS

Certain parameters should be programmable (and therefore easily modified) for easy upgrade.

- a) Pulse width
- b) Maximum number of pulses, current limit 8.
- c) Number of over-programming pulses: should be =  $(A \cdot N) + B$ , where N = number of pulses required in regular programming. In our current algorithm A = 11, B = 0.

#### 1.5 Programming Pulse Width

**Program Memory Cells**: When programming one word of EPROM, a programming pulse width (TPW) of 100  $\mu$ s is recommended.

The maximum number of programming attempts should be limited to 8 per word.

After the first successful verify, the same location should be over-programmed with 11X over-programming.

**Configuration Word**: The configuration word for oscillator selection, WDT (watchdog timer) disable and code protection, requires a programming pulse width (TPWF) of 10 ms. A series of 100  $\mu$ s pulses is preferred over a single 10 ms pulse.







#### FIGURE 1-2: PIC16C5X SERIES PROGRAM MEMORY MAP IN PROGRAM/VERIFY MODE

#### 1.6 Special Memory Locations

The ID Locations area is only enabled if the device is in a test or programming/verify mode. Thus, in normal operation mode only the memory location 0x000 to 0xNNN will be accessed and the Program Counter will just roll over from address 0xNNN to 0x000 when incremented.

The configuration word can only be accessed immediately after MCLR going from VIL to VHH. The Program Counter will be set to all '1's upon MCLR = VIL. Thus, it has the value "0xFFF" when accessing the configuration EPROM. Incrementing the Program Counter once by pulsing OSC1 causes the Program Counter to roll over to all '0's. Incrementing the Program Counter 4K times after reset (MCLR = VIL) does not allow access to the configuration EPROM.

#### 1.6.1 CUSTOMER ID CODE LOCATIONS

Per definition, the first four words (address TTT to TTT + 3) are reserved for customer use. It is recommended that the customer use only the four lower order bits (bits 0 through 3) of each word and filling the eight higher order bits with '0's.

A user may want to store an identification code (ID) in the ID locations and still be able to read this code after the code protection bit was programmed. This is possible if the ID code is only four bits long per memory location, is located in the least significant nibble boundary of the 12-bit word, and the remaining eight bits are all '0's.

#### EXAMPLE 1: CUSTOMER CODE 0xD1E2

The Customer ID code "0xD1E2" should be stored in the ID locations 200-203 like this:

200:	0000	0000	1101
201:	0000	0000	0001
202:	0000	0000	1110
203:	0000	0000	0010

Reading these four memory locations, even with the code protection bit programmed would still output on Port A the bit sequence "1101", "0001", "1110", "0010" which is "0xD1E2".

**Note:** Microchip will assign a unique pattern number for QTP and SQTP requests and for ROM devices. This pattern number will be unique and traceable to the submitted code.

## 2.0 CONFIGURATION WORD

The configuration word is the very first memory location which is accessed after entering the program/verify mode of the PIC16C5X. It contains the two bits for the selection of the oscillator type, the watchdog timer enable bit, and the code protection bit. All other bits (4 through 11) are read as '1's. One-Time-Programmable (OTP) devices may have the oscillator configuration bits "FOSC0" and "FOSC1" set by the factory and are tested accordingly. Therefore, it is essential that the inputs RA0 and RA1 are held at '1's when programming the "WDTE" and/or the "CP" bit of the configuration word. Otherwise, the factory tested and selected oscillator configuration could be overwritten and the functionality of the device is not guaranteed any more.

#### FIGURE 2-1: CONFIGURATION WORD FOR PIC16CR54A/C54B/CR54B/C54C/CR54C/C55A/C56A/ CR56A/C57C/CR57B/CR57C/C58B/CR58A/CR58B

CP	СР	CP	CP	CP	CP	CP	CP	CP	WDTE	FOSC1	FOSC0	Register:	CONFIG
bit11	10	9	8	7	6	5	4	3	2	1	bit0	Address:	FFFh
oit 11-3:	1 = Cc	CP: Code protection bits 1 = Code protection off 0 = Code protection on											
oit 2:	1 = W	VDTE: Watchdog timer enable bit = WDT enabled = WDT disabled											
oit 1-0:	0 = WDT disabled <b>FOSC1:FOSC0:</b> Oscillator selection bits 11 = RC oscillator 10 = HS oscillator 01 = XT oscillator 00 = LP oscillator												

#### FIGURE 2-2: CONFIGURATION WORD FOR PIC16C52/C54/C54A/C55/C56/C57/C58A

—	—	—			—			CP	WDTE	FOSC1	FOSC0	Register:	CONFIG
bit11	10	9	8	7	6	5	4	3	2	1	bit0	Address:	FFFh
bit 11-4:	Unim	olemente	ed: Read	as '0'									
bit 3:	1 = Co	CP: Code protection bit. = Code protection off = Code protection on											
bit 2:	1 = W	E: Watcho DT enabl DT disab	led	r enable	bit (not	impleme	ented or	n PIC16	6C52)				
bit 1-0:	11 = F 10 = F 01 = X	A:FOSC C oscilla S oscilla T oscilla P oscilla	ator itor tor	ator seled	ction bits	(2)							
Note:	PIC	C16LV54	1A supp	orts XT	RC an	scillator d LP os d LP os	cillator of						

## 3.0 CODE PROTECTION

The program code written into the EPROM can be protected by writing to the "CP" bit of the configuration word. All memory locations starting at 0x40 and above are protected against programming. It is still possible to program locations 0x00 through 0x3F, the ID locations, and the configuration word.

Note:	Locations [0x000 : 0x03F] are not secure
	after code protection.

#### 3.1 <u>Programming Locations 0x000 to</u> 0x03F after Code Protection

In a code protected part, these locations will program with the exception of the PIC16CRXX devices. They will read back scrambled data, with the exception of PIC16CR54A and PIC16CR58A. In any event, the programmer cannot verify the device once it is code protected.

In code protected parts, the contents of the program memory cannot be read out in a way that the program code can be reconstructed. A location when read out will read as: 0000 0000 xxxx where xxxx is the XOR of the three nibbles. For example, if the memory location contains 0xC04 (movlw 4), after code protection the output will be 0x008.

In addition, all memory locations starting at 0x40 and above are protected against programming. It is still possible to program locations 0x000 through 0x03F and the configuration word. However, performing a verify with activated code protection logic puts a 4-bit wide "checksum" on PORTA while the 8-bits of PORTB are read as '0's. The checksum is computed as follows:

The four high order bits of an instruction word are "XOR'ed" with the four middle and the four low order bits, and the result is transferred to PORTA. All memory locations are affected.

To program location 0x000 to 0x03F in a code protected part, the programmer should program one nibble at a time and verify the result through the XOR'ed output. For example, to program a location with 0xA93, first program the location with 0xFF3, verify checksum to be 0x003; then program the location with 0xF93 and verify the XOR'ed output to be 0x00C and finally program the location with 0xA93 and verify the read-out to be 0x006.

### 3.2 Embedding Configuration Word and ID Information in the Hex File

To allow portability of code, a PIC16C5X programmer is required to read the configuration word and ID locations from the hex file when loading the hex file. If configuration word information was not present in the hex file then a simple warning message may be issued. Similarly, while saving a hex file, all configuration word and ID information must be included. Configuration word should have the address of 0xFFF. ID locations are mapped at addresses described in Section 1.6.1 and Table 3-1. An option to not include this information may be provided.

Microchip Technology Inc. feels strongly that this feature is important for the benefit of the end customer.

## TABLE 3-1:CONFIGURATION WORD

#### 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x17F]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x1FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x1FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### PIC16CR54A (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Unscrambled	Read Unscrambled
ID Words [0x800 : 0x803]	Read Unscrambled	Read Unscrambled
[0x040 : 0x7FF]	Read Disabled	Read Unscrambled
[0x000 : 0x03F]	Read Unscrambled	Read Unscrambled

## PIC16C54B (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x1FF]	Read 0's, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled

## PIC16CR54B (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Unscrambled	Read Unscrambled
ID Words [0x800 : 0x803]	Read Unscrambled	Read Unscrambled
[0x040 : 0x7FF]	Read 0's	Read Unscrambled
[0x000 : 0x03F]	Read Unscrambled	Read Unscrambled

#### PIC16C54C (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x1FF]	Read 0's Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled

## PIC16CR54C (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Unscrambled	Read Unscrambled
ID Words [0x800 : 0x803]	Read Unscrambled	Read Unscrambled
[0x040 : 0x7FF]	Read 0's	Read Unscrambled
[0x000 : 0x03F]	Read Unscrambled	Read Unscrambled

#### PIC16C55 (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x1FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### PIC16C55A (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x200 : 0x203]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x1FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x400 : 0x403]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x3FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

## PIC16C56A (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x400 : 0x403]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x3FF]	Read 0's	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### PIC16CR56A (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x400 : 0x403]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x3FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x800 : 0x803]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x7FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

### PIC16C57C (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x800 : 0x803]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x7FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### PIC16CR57B (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x800 : 0x803]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x7FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### PIC16CR57C (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x800 : 0x803]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x7FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

#### 

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode
Configuration Word (0xFFF)	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
ID Words [0x800 : 0x803]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled
[0x040 : 0x7FF]	Read Scrambled, Write Disabled	Read Unscrambled, Write Enabled
[0x000 : 0x03F]	Read Scrambled, Write Enabled	Read Unscrambled, Write Enabled

## PIC16CR58A (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode		
Configuration Word (0xFFF)	Read Unscrambled	Read Unscrambled		
ID Words [0x800 : 0x803]	Read Unscrambled	Read Unscrambled		
[0x040 : 0x7FF]	Read Disabled	Read Unscrambled		
[0x000 : 0x03F]	Read Unscrambled	Read Unscrambled		

#### PIC16C58B (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode		
Configuration Word (0xFFF)	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled		
ID Words [0x800 : 0x803]	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled		
[0x040 : 0x7FF]	Read 0s, Write Disabled	Read Unscrambled, Write Enabled		
[0x000 : 0x03F]	Read Unscrambled, Write Enabled	Read Unscrambled, Write Enabled		

#### PIC16CR58B (CP enable pattern: 00000000XXX)

Program Memory Segment	R/W in Protected Mode	R/W in Unprotected Mode		
Configuration Word (0xFFF)	Read Unscrambled	Read Unscrambled		
ID Words [0x800 : 0x803]	Read Unscrambled	Read Unscrambled		
[0x040 : 0x7FF]	Read 0's	Read Unscrambled		
[0x000 : 0x03F]	Read Unscrambled	Read Unscrambled		

Legend: X = Don't care

#### 3.3 Checksum

#### 3.3.1 CHECKSUM CALCULATIONS

Checksum is calculated by reading the contents of the PIC16C5X memory locations and adding up the opcodes up to the maximum user addressable location, e.g., 0x1FF for the PIC16C54/55. Any carry bits exceeding 16-bits are neglected. Finally, the configuration word (appropriately masked) is added to the checksum. Checksum computation for each member of the PIC16C5X devices is shown in Table .

The checksum is calculated by summing the following:

- The contents of all program memory locations
- The configuration word, appropriately masked
- Masked ID locations (when applicable)

The least significant 16 bits of this sum is the checksum.

The following table describes how to calculate the checksum for each device. Note that the checksum calculation differs depending on the code protect setting. Since the program memory locations read out differently depending on the code protect setting, the table describes how to manipulate the actual program memory values to simulate the values that would be read from a protected device. When calculating a checksum by reading a device, the entire program memory can simply be read and summed. The configuration word and ID locations can always be read.

Note that some older devices have an additional value added in the checksum. This is to maintain compatibility with older device programmer checksums.

Device	Code Protect	Checksum*	Blank Value	0x723 at 0 and max address
PIC16C52	OFF	SUM[0x000:0x17F] + CFGW & 0x00B	0xFE8B	0xECD3
	ON	SUM_XOR4[0x000:0x17F] + CFGW & 0x00B	0x1683	0x1671
PIC16C54	OFF	SUM[0x000:0x1FF] + CFGW & 0x00F + 0x0FF0	0x0DFF	0xFC47
	ON	SUM_XOR4[0x000:0x1FF] + CFGW & 0x00F	0x1E07	0x1DF5
PIC16C54A	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM_XOR4[0x000:0x1FF] + CFGW & 0x00F	0x1E07	0x1DF5
PIC16C54B	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM[0x00:0x3F] + CFGW & 0xFFF + SUM_1D	0x0DC6	0xF332
PIC16C54C	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM[0x00:0x3F] + CFGW & 0xFFF + SUM_1D	0x0DC6	0xF332
PIC16CR54A	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM[0x00:0x3F] + CFGW & 0xFFF + SUM_1D	0x0DC6	0xF332
PIC16CR54B	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM[0x00:0x3F] + CFGW & 0xFFF + SUM_1D	0x0DC6	0xF332
PIC16CR54C	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM[0x00:0x3F] + CFGW & 0xFFF + SUM_1D	0x0DC6	0xF332
PIC16C55	OFF	SUM[0x000:0x1FF] + CFGW & 0x00F + 0x0FF0	0x0DFF	0xFC47
	ON	SUM_XOR4[0x000:0x1FF] + CFGW & 0x00F	0x1E07	0x1DF5
PIC16C55A	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0DFF	0xFC47
	ON	SUM[0x000:0x3F] + CFGW & 0xFFF + SUM_ID	0x0DC6	0xF322
PIC16C56	OFF	SUM[0x000:0x3FF] + CFGW & 0x00F + 0x0FF0	0x0BFF	0xFA47
	ON	SUM_XOR4[0x000:0x3FF] + CFGW & 0x00F	0x3C07	0x3BF5
PIC16C56A	OFF	SUM[0x000:0x3FF] + CFGW & 0xFFF	0x0BFF	0xFA47
	ON	SUM_XOR4[0x000:0x3F] + CFGW & 0x00F + SUM_ID	0x0BC6	0xF132

#### TABLE 3-1: CHECKSUM COMPUTATION

Legend: CFGW = Configuration Word

SUM[a:b] = Sum of locations a through b inclusive

SUM\_XOR4[a:b] = XOR of the four high order bits with the four middle and the four low of memory location order bits summed over the locations a through b inclusive. For example, location\_a = 0x123 and

location\_b = 0x456, then SUM\_XOR [location\_a : location\_b] = 0x0007.

SUM\_ID = ID locations masked by 0xF then made into a 16-bit value with ID0 as the most significant nibble.

For example, ID0 = 0x1, ID1 = 0x2, ID3 = 0x3, ID4 = 0x4, then SUM\_ID = 0x1234.

\*Checksum = Sum of all individual expressions modulo [0xFFFF]

+ = Addition

& = Bitwise AND

Device	Code Protect	Checksum*	Blank Value	0x723 at 0 and max address
PIC16CR56A	OFF	SUM[0x000:0x1FF] + CFGW & 0xFFF	0x0BFF	0xFA47
	ON	SUM[0x000:0x3F] + CFGW & 0xFFF + SUM_ID	0x0BC6	0xF132
PIC16C57	OFF	SUM[0x000:0x7FF] + CFGW & 0x00F + 0x0FF0	0x07FF	0xF647
	ON	SUM_XOR4[0x000:0x7FF] + CFGW & 0x00F	0x7807	0x77F5
PIC16C57C	OFF	SUM[0x000:0x7FF] + CFGW & 0xFFF	0x07FF	0xF647
	ON	SUM[0x000:0x3F] + CFGW & 0xFFF + SUM_ID	0x07C6	0xED32
PIC16CR57A	OFF	SUM[0x000:0x7FF] + CFGW & 0x00F + FF0	0x07FF	0xF647
	ON	SUM_XOR4[0x00:0x7FF] + CFGW & 0xF	0x7807	0x77F5
PIC16CR57B	OFF	SUM[0x000:0x7FF] + CFGW & 0xFFF	0x07FF	0xF647
	ON	SUM[0x00x:0x3F] + CFGW & 0xFFF + SUM_ID	0x07C6	0xED32
PIC16CR57C	OFF	SUM[0x000:0x7FF] + CFGW & 0xFFF	0x07FF	0xF647
	ON	SUM[0x00x:0x3F] + CFGW & 0xFFF + SUM_ID	0x07C6	0xED32
PIC16C58A	OFF	SUM[0x000:0x7FF] + CFGW & 0x00F + 0x0FF0	0x07FF	0xF647
	ON	SUM_XOR4[0x000:0x7FF] + CFGW & 0x00F	0x7807	0x77F5
PIC16C58B	OFF	SUM[0x000:0x7FF] + CFGW & 0xFFF	0x07FF	0xF647
	ON	SUM[0x000:0x7FF] + CFGW & 0xFFF + SUM_ID	0x7C6	0xED32
PIC16CR58A	OFF	SUM[0x000:0x7FF] + CFGW & 0xFFF	0x07FF	0xF647
	ON	SUM[0x000:0x3F] + CFGW & 0xFFF + SUM_ID	0x07C6	0xED32
PIC16CR58B	OFF	SUM[0x000:0x7FF] + CFGW & 0xFFF	0x07FF	0xF647
	ON	SUM[0x000:0x3F] + CFGW & 0xFFF + SUM_ID	0x07C6	0xED32

Legend: CFGW = Configuration Word

SUM[a:b] = Sum of locations a through b inclusive

SUM\_XOR4[a:b] = XOR of the four high order bits with the four middle and the four low of memory location order bits summed over the locations a through b inclusive. For example, location\_a = 0x123 and

location\_b = 0x456, then SUM\_XOR [location\_a : location\_b] = 0x0007.

SUM\_ID = ID locations masked by 0xF then made into a 16-bit value with ID0 as the most significant nibble. For example, ID0 = 0x1, ID1 = 0x2, ID3 = 0x3, ID4 = 0x4, then SUM\_ID = 0x1234.

\*Checksum = Sum of all individual expressions modulo [0xFFF]

+ = Addition

& = Bitwise AND

## 4.0 PROGRAM/VERIFY MODE ELECTRICAL CHARACTERISTICS

#### 4.1 DC Program Characteristics)

Parameter No.	Symbol	Characteristics	Min.	Тур.	Max.	Units	Conditions
PD1	VDDP	Supply voltage during pro- gramming	4.75	5.0	5.25	V	Note 1
PD2	IDDP	Supply Current (from VDD)			25.0	mA	VDD = 5.0V, Fosc1 = 5MHz
PD3	Vddv	Supply Voltage during verify	Vddmin		VDDmax		
PD5	Vнн2	Voltage on MCLR during pro- gramming	12.5		13.5	V	
PD6	Інн	Supply current from program- ming voltage source			100	mA	
PD7	Інн2	Current into MCLR pin during programming (T0CKI=0)		10.0	25.0	mA	VHH = 13.5V, VDD = 6.0V
PD8	VIL	Input Low Voltage	Vss		0.15Vdd	V	
PD9	Vін	Input High Voltage	0.85Vdd	5.0	Vdd	V	

#### TABLE 4-1:DC CHARACTERISTICS (TA = +10°C TO +40°C) (25°C IS RECOMMENDED

Note 1: Device must be verified at minimum and maximum operating voltages specified in the data sheet.

#### 4.2 AC Program and Test Mode Characteristics

## TABLE 4-1:AC CHARACTERISTICS (TA = $+10^{\circ}$ C TO $+40^{\circ}$ C, VDD = $5.0V \pm 5\%$ )<br/>(25°C IS RECOMMENDED

Parameter No.	Symbol	Characteristics	Min	Тур	Max	Units	Conditions
P1	TR	MCLR Rise Time	0.15	1.0	8	μs	
P2	TF	MCLR Fall Time	0.5	2.0	8	μs	
P3	TPS	Program Mode Setup Time	1.0			μs	
P4	TACC	Data Access Time			250	ns	
P5	TDS	Data Setup Time	1.0			μs	
P6	Трн	Data Hold Time	1.0			μs	
P7	TOE	Output Enable Time	0		100	ns	
P8	Toz	Output Disable Time	0		100	ns	
P9	TPW	Programming Pulse Width	10.0	100		μs	
P10	TPWF	Programming Pulse Width		10,000		μs	Configuration Word only
P11	TRC	Recovery Time	10.0			μs	
P12	Fosc	Frequency on OSC1	DC		5	MHz	For incrementing of the PC



#### FIGURE 4-1: PROGRAMMING AND VERIFY TIMING WAVEFORM





NOTES:



## WORLDWIDE SALES AND SERVICE

#### AMERICAS

**Corporate Office** Microchip Technology Inc. 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-786-7200 Fax: 480-786-7277 Technical Support: 480-786-7627 Web Address: http://www.microchip.com

#### Atlanta

Microchip Technology Inc. 500 Sugar Mill Road, Suite 200B Atlanta, GA 30350 Tel: 770-640-0034 Fax: 770-640-0307

#### Boston

Microchip Technology Inc. 5 Mount Royal Avenue Marlborough, MA 01752 Tel: 508-480-9990 Fax: 508-480-8575

#### Chicago

Microchip Technology Inc. 333 Pierce Road, Suite 180 Itasca, IL 60143 Tel: 630-285-0071 Fax: 630-285-0075

#### Dallas

Microchip Technology Inc. 4570 Westgrove Drive, Suite 160 Addison, TX 75248 Tel: 972-818-7423 Fax: 972-818-2924

#### Dayton

Microchip Technology Inc. Two Prestige Place, Suite 150 Miamisburg, OH 45342 Tel: 937-291-1654 Fax: 937-291-9175

#### Detroit

Microchip Technology Inc. Tri-Atria Office Building 32255 Northwestern Highway, Suite 190 Farmington Hills, MI 48334 Tel: 248-538-2250 Fax: 248-538-2260

#### Los Angeles

Microchip Technology Inc. 18201 Von Karman, Suite 1090 Irvine, CA 92612 Tel: 949-263-1888 Fax: 949-263-1338

#### **New York**

Microchip Technology Inc. 150 Motor Parkway, Suite 202 Hauppauge, NY 11788 Tel: 613-273-5305 Fax: 613-273-5335

#### San Jose

Microchip Technology Inc. 2107 North First Street, Suite 590 San Jose, CA 95131 Tel: 408-436-7950 Fax: 408-436-7955

## **AMERICAS** (continued)

Toronto

Microchip Technology Inc. 5925 Airport Road, Suite 200 Mississauga, Ontario L4V 1W1, Canada Tel: 905-405-6279 Fax: 905-405-6253 ASIA/PACIFIC

Hong Kong Microchip Asia Pacific Unit 2101, Tower 2 Metroplaza 223 Hing Fong Road Kwai Fong, N.T., Hong Kong Tel: 852-2-401-1200 Fax: 852-2-401-3431 Beijing Microchip Technology, Beijing Unit 915, 6 Chaoyangmen Bei Dajie Dong Erhuan Road, Dongcheng District New China Hong Kong Manhattan Building Beijing 100027 PRC Tel: 86-10-85282100 Fax: 86-10-85282104 India Microchip Technology Inc. India Liaison Office No. 6, Legacy, Convent Road Bangalore 560 025, India Tel: 91-80-229-0061 Fax: 91-80-229-0062 Japan Microchip Technology Intl. Inc. Benex S-1 6F 3-18-20, Shinyokohama Kohoku-Ku, Yokohama-shi Kanagawa 222-0033 Japan Tel: 81-45-471- 6166 Fax: 81-45-471-6122 Korea Microchip Technology Korea 168-1, Youngbo Bldg. 3 Floor Samsung-Dong, Kangnam-Ku Seoul, Korea Tel: 82-2-554-7200 Fax: 82-2-558-5934 Shanghai Microchip Technology RM 406 Shanghai Golden Bridge Bldg. 2077 Yan'an Road West, Hong Qiao District

Shanghai, PRC 200335 Tel: 86-21-6275-5700 Fax: 86 21-6275-5060

#### **ASIA/PACIFIC** (continued)

Singapore Microchip Technology Singapore Pte Ltd. 200 Middle Road #07-02 Prime Centre Singapore 188980 Tel: 65-334-8870 Fax: 65-334-8850

Taiwan, R.O.C

Microchip Technology Taiwan 10F-1C 207 Tung Hua North Road

Taipei, Taiwan, ROC

Tel: 886-2-2717-7175 Fax: 886-2-2545-0139 **EUROPE** 

#### **United Kingdom**

Arizona Microchip Technology Ltd. 505 Eskdale Road Winnersh Triangle Wokingham Berkshire, England RG41 5TU Tel: 44 118 921 5858 Fax: 44-118 921-5835

#### Denmark

Microchip Technology Denmark ApS **Regus Business Centre** Lautrup hoj 1-3 Ballerup DK-2750 Denmark Tel: 45 4420 9895 Fax: 45 4420 9910

#### France

Arizona Microchip Technology SARL Parc d'Activite du Moulin de Massy 43 Rue du Saule Trapu Batiment A - ler Etage 91300 Massy, France Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

#### Germany

Arizona Microchip Technology GmbH Gustav-Heinemann-Ring 125 D-81739 München, Germany Tel: 49-89-627-144 0 Fax: 49-89-627-144-44 Italy

Arizona Microchip Technology SRL Centro Direzionale Colleoni Palazzo Taurus 1 V. Le Colleoni 1 20041 Agrate Brianza Milan, Italy Tel: 39-039-65791-1 Fax: 39-039-6899883

11/15/99

DNV Certification, Inc. DNV MSC USA The Netherlands Accredited by the RvA ANSI \* RAB CCRED DIN ISO 9001 / QS-9000 REGISTERED FIRM

Microchip received QS-9000 quality system certification for its worldwide headquarters design and wafer fabrication facilities in Chandler and Tempe, Arizona in July 1999. The Company's quality system processes and procedures are QS-9000 compliant for its PICmicro<sup>®</sup> 8-bit MCUs, KEELOQ<sup>®</sup> code hopping devices, Serial EEPROMs and microperipheral products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001 certified.

All rights reserved. 💿 1999 Microchip Technology Incorporated. Printed in the USA. 11/99 🔬 Printed on recycled paper.

Information contained in this publication regarding device applications and the like is intended for suggestion only and may be superseded by updates. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such Information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No incorposed, implicitly or otherwise, under any intellectual property rights. The Microchip logo and name are registered trademarks of Microchip Technology Inc. in the U.S.A. and other countries. All rights reserved. All other trademarks mentioned herein are the property of their respective companies.

