


4-13. SCHEMATIC DIAGRAM – PANEL Section (2/3) – • See page 32 for Waveforms.




(1) (Page 24)

(3) (Page 26)

- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- no mark : FM
- () : CD PLAY

(A) (Page 15)

4-14. SCHEMATIC DIAGRAM - PANEL Section (3/3) -



* LED910, 911
SEL1410G

* LED909
SEL1110R

IC602
LED DRIVER

* LED903-908
SEL1710Y

LED903 CD
LED904 TAPE A/B
LED905 TUNER/BAND
LED906 MD
LED907 GROOVE

• Voltages are dc with respect to ground under no-signal (detuned) conditions.
no mark : FM