
USBASP TO VCDS ATMEGA CHIP CONNECTION


Close jumper J1 or JP1 on USBASP to establish 5V power.



INTERFACE TO USBASP CONNECTION



FOR HQ HARDWARE CLONE USE THIS PINOUT:



For chinese interface with stc chip, remove that.

