


## CONTROL LOCATIONS



NO.	Ref. No.	Control Function
1	SW 201	POWER SWITCH
2	VR 202	CONTRAST ( ● )
3	VR 201	BRIGHTNESS ( ☀ )
4	SW205	SELECT RIGHT ( ◀ )
5	SW203	ENTER BUTTON
6	SW204	EXIT BUTTON
7	SW202	SELECT LEFT ( ▶ )
8	VR 517	ABL ADJUSTMENT
9	VR955	B <sup>+</sup> ADJUSTMENT
10	VR548	HIGH-VOLTAGE ADJUSTMENT
11	SW501	RASTER CENTER SWITCH